

Valid as of January 2024



leica-geosystems.com



- when it has to be **right**

FEATURE	STANDARD (BASE)	SURVEY (OPTION)	AEC (OPTION)	PLANT (OPTION)	PRO (EDITION)
POINT CLOUD PROCESSING					
Noise detection	•				•
Clean/Separate clouds by fence	•				•
Separate with object	•				•
Reduce	•				•
Density homogenisation	•				•
Segmentation (by distance, scan station and colour)	*				•
Target extraction		•	•		•
Detect moving objects	•				•
Ground extractor filter		•			•
Walls and floors filter		•	•	•	•
Tunnel filter		•	•		•
Automatic Classification / Manual Classification		•	•	•	•
Explode by class / Class representation / Support of classification with LAS-LAZ, LGSx and e57	•				•
Points on grid (ground, lowest, highest)	•				•
			ļ		1
CLOUDWORX					
Connect to Cyclone IMP, LGSx and Cyclone ENTERPRISE server	*				•
Create UCS and align views	•				•
Create and manage limit boxes, limit slices and limit	•				•
planes					
				1	
Reality Cloud Studio, powered by HxDR					
Connect to Reality Cloud Studio	•				•
	•				•
Past align N points	•				•
Best digit N points	•				•
PIM Alignment	•				•
bin Aignment			•	•	•
Scan to Mesh	•				•
3D meshing	•				•
Spherical meshing	•				•
2D meshing	•				•
Mesh refining: smoothing (including locally with	•				•
brush), decimation, hole filling sharp, edges and bor-					
ders reconstruction, junctions, cut mesh, inspection steps, subdivide					
Mesh extrusion	•				•
Mesh convex hull	•				•
Meshing under constraints (with polylines)	•				•
Mesh segmentation	•				•
Spikes detection	•				•
Write on mesh	•				•
			1	1	1

FEATURE	STANDARD (BASE)	SURVEY (OPTION)	AEC (OPTION)	PLANT (OPTION)	PRO (EDITION)
SURFACE MODELLING (CONT.)					
DSM and DTM creation		•			•
Building extraction		•	•		•
Clean / Separate Mesh (selection zone, size)	*				•
Mesh Extraction from BIM models	*				•
Subdivide Mesh	*				•
CONTROL/INSPECTION/ANALYSIS					
Angle, distance, geometry	*				•
Cubature/volume	*				•
Geometric shape extraction	*				•
3D inspection	*				•
2D inspection	*				•
BIM inspection			•	•	•
Reporting (CSV, PDF and 3DPDF)	*				•
Stockpile Measurement		•			•
Progress Monitoring / Export BCF			•		•
Profile Extraction and Analysis for tunnels and roads (creation, inspection, volumes, unroll)		•	•		•
Surface Analysis (levelness, flatness, slope) / Gridded Inspection		•	•		•
Clash Analysis / Export BCF clashes			•	•	•
Inspection Notes and Visual Notes/ Export BCF			•	•	•
POLYLINES/SECTION/EXTRACT					
Sections (planar, radial, etc.)	*				•
Smoothing	*				•
Decimation	*				•
Chaining	*				•
Neutral axis extraction	•				•
Breakline extraction (single)	•				•
Planar contour extraction	•				•
Contour lines		•			•
Virtual Surveyor		•			•

virtual Surveyor		•			•
Breakline extraction (multiple)		•			•
Polyline edition (stretch, edit, resample, replace)	•				•
Scan-to-Plan			•		•
Scan-to-Pipe				•	•

IMAGE/TEXTURE MANAGEMENT				
Conversion between inspected or coloured mesh to textured mesh		•		*
Automatic and manual mapping of pin hole, cube faces and spherical images		•		*
Automatic and manual mapping of orthoimages		•		•
Texture from clouds	•			•
Camera calibration		•		•
Creation of texture atlas		•		•

FEATURE	STANDARD (BASE)	SURVEY (OPTION)	AEC (OPTION)	PLANT (OPTION)	PRO (EDITION)
IMAGE/TEXTURE MANAGEMENT (CONT.)					
Texture edition (adjust, explode, remove)		•			•
Texture from material		•			•
Smart Texture		•			•
Orthoimage (including georeferencing information as word file)		•			•
Edition of image masks		•			•
				1	
REVERSE ENGINEERING					
IGES, STEP and DXF import	•				•
REVIT, IFC, and DWG import			•	•	•
CAD Surface creation			•		•
Local or overall surface improvements			•		•
Support of measuring arm with RDS			•		•
IFC Export (meshes)			•	•	•
Reverse engineering workflow (creation and edition of networks, CAD surface generation based on networks, manage overlapped surface, export in IGES/ STEP)			•		*
IGES/STEP export (geometrical shapes and existing CAD model)	•				•
				L	
USER INTERFACE					
Orthographic and perspective view	•				•
Multiview with synchronisation	•				•
Tree explorer	•				•
AutoSaves	•				•
Clipping box and plane	•				•
Grid	•				•
Shortcuts	•				•
Send to/Send from AutoCAD	•				•
Send to/Send from Hexagon MinePlan	•				•
Send to/Send from Hexagon BricsCAD	•				•
Import from Cyclone FIELD 360	•				•
Localisation	•				•
Cyclone camera	•				•
Navigation through TLS and MMS scanner setups	•				•
Scan trajectory import / export in LGSx (Dynamic scanners)	•				•
Basic Point selection tools (selection, vertex, nearest, middle, intersection, XYZ)	•				•
Advanced Point selection tools (target, highest, low- est)		•	•		•
Survey Point selection tools (ground, white line)		•			•
Objects display management	•				•
Capture view	•				•
Stereo Rendering	•				•

FEATURE	STANDARD (BASE)	SURVEY (OPTION)	AEC (OPTION)	PLANT (OPTION)	PRO (EDITION)
TOUCH MODE WORKFLOWS					
360			•		•
	I		1	1	
AUTOMATION					
Scripting	•				*
I					
ANIMATION					
Animation - Video	•				*
RDS CONNECTION					
Online data capture and visualisation	•				*
TANK MONITORING MODULE					
3D inspection				•	•
Roundness and verticality				•	•
Settlements				•	•
Export and reporting				•	•
POINT CLOUD IMPORT FORMATS					
Leica Geosystems (*.pts, *.ptx) and LGSx (*.lgsx)	•				•
Leica Nova MS50/60 (*.sdb, *.xml)	•				•
ShapeGrabber (*.3pi)	•				•
3DReshaper binary file (*.nsd)	•				•
AutoDesk DXF (*.dxf)	•				•
SIL (*.sti)	•				•
Polyworks (*.psi)	•				•
	•				•
	•				•
Zoller and Eröblich (* zfs - * zfc)	•				•
PLY points without triangles (* ply)	•				•
FSRI ASCII (raster format * asc)	•				•
FARO (* fls - * fws)	•				•
POLYWORKS (*.psl)	•				•
E57 (*.E57)	•				•
LandXML files (*.xml)	•				•
RDBX	•				•
	l		I	I	
MESH IMPORT FORMATS					
STL format (*.stl)	•				*
Binary PBI format (*.pbi)	•				*
DXF 3Dface format (*.dxf)	•				•
ASCII POLY format (*.poly)	•				•
OBJ format (*.obj)	•				•
ASCII Leica format (*.msh)	•				•
OFF files (*.off)	•				•
PLY (*.ply)	•				•
GLB files (*.glb, *.glft)	*				*

FEATURE	STANDARD (BASE)	SURVEY (OPTION)	AEC (OPTION)	PLANT (OPTION)	PRO (EDITION)
CONTOUR/SECTION IMPORT FORMATS					
IGES format	•				•
DXF polyline format	•				•
Binary MLI format (*.mli)	•				•
				1	
CAD MODEL IMPORT FORMATS					
IGES	•				+
STEP	•				•
DWG			•	•	•
BIM MODEL IMPORT FORMATS					
IFC			•	•	•
RVT			•	•	•
POINT CLOUD EXPORT FORMATS					
ASCII FILES (*.asc, *.csv)	•				•
Binary files (*.nsd)	•				•
Leica Geosystems (*.pts, *.ptx) and LGSx (*.lgsx)	•				•
E57 (*.e57) including images	•				•
IGES (*.igs)	•				•
LAS (*.las)	•				•
LAZ (*.laz)	•				•
AutoDesk DXF (*.dxf)	•				•
LGSx (point cloud, UCS, limit box, trajectory)	•				•
MESH EXPORT FORMATS					
ASCII and binary STL format (*.stl)	•				•
Binary PBI format (*.pbi)	•				•
DXf 3Dface format (*.dxf)	•				•
ASCII POLY format (*.poly)	•				•
Vertices only (*.asc)	•				•
DXF polyline (*.dxf)	•				•
STEP file (*.stp)	•				•
ASCII Leica format (*.msh)	•				•
PLY (*.ply)	•				+

PLY (*.ply)	•			•
LandXML (*.xml)	•			•
OBJ format (*.obj)	•			•
GLB files (*.glb)	•			•
FBX files (*.fbx)	•			*
	·		•	

CONTOUR/SECTION EXPORT FORMATS					
IGES format	•				•
DXF polyline format	•				•
Binary MLI format (*.mli)	•				•
ASCII formats	•				•

FEATURE	STANDARD (BASE)	SURVEY (OPTION)	AEC (OPTION)	PLANT (OPTION)	PRO (EDITION)
				,	
CAD/BIM MODEL EXPORT FORMATS					
IGES (geometrical shapes and existing CAD model)	•				•
STEP (geometrical shapes and existing CAD model)	•				•
Image export format	•				•
Orthoimage including georeferencing information as World file	*				•
IFC Piping models				•	•
PROJECT FILES - EXPORT					
RESHAPER (*.rsh)	•				•
DXF	•				•
PDF 3D	•				•
SKETCHFAB	•				•
PUBLISHING FEATURES					
Publish Point Cloud to LGS	•				•

Recommended Specifications

Processor	2 GHz Dual Quad Core i7 processor or better
RAM	Minimum 16 GB or more for 64 bit OS
Hard Disk	3 GB free disk space
Graphic Card	Nvidia - Quadro or GeForce 1 GB (with OpenGL support, versions 4.3 or higher)
Operating System	Microsoft Windows® 10 (Build 1809) – 11 (64 bits supported)
Tablet Device for Touch Mode	Microsoft Surface PRO Core i7 1.5 GHz – 16GB RAM
Minimum requirements for Automatic Classification	Graphic card: Nvidia with GPU capabilities Minimum GPU Memory: 4 GB Compute capability: 5.0 or higher RAM: 32 GB Hard disk: 10 GB free disk space CUDA® 11.8 Toolkit from Nvidia

Edition Components

Cyclone 3DR Survey Edition	Cyclone 3DR Standard Cyclone 3DR Survey Option
Cyclone 3DR AEC Edition	Cyclone 3DR Standard Cyclone 3DR AEC Option
Cyclone 3DR Plant Edition	Cyclone 3DR Standard Cyclone 3DR Plant Option
Cyclone 3DR Pro Edition	Cyclone 3DR Standard Cyclone 3DR Survey Option Cyclone 3DR AEC Option Cyclone 3DR Plant Option

Revolutionising the world of measurement and survey for nearly 200 years, Leica Geosystems, part of Hexagon, creates complete solutions for professionals across the planet. Known for premium products and innovative solution development, professionals in a diverse mix of industries, such as aerospace and defence, safety and security, construction, and manufacturing, trust Leica Geosystems for all their geospatial needs. With precise and accurate instruments, sophisticated software, and trusted services, Leica Geosystems delivers value every day to those shaping the future of our world.

Hexagon is a global leader in sensor, software and autonomous solutions. We are putting data to work to boost efficiency, productivity, and quality across industrial, manufacturing, infrastructure, safety, and mobility applications. Our technologies are shaping urban and production ecosystems to become increasingly connected and autonomous — ensuring a scalable, sustainable future.

Hexagon (Nasdaq Stockholm: HEXA B) has approximately 21,000 employees in 50 countries and net sales of approximately 3.8bn EUR. Learn more at <u>hexagon.com</u> and follow us <u>@HexagonAB</u>.

Copyright Leica Geosystems AG, 9435 Heerbrugg, Switzerland. All rights reserved. Printed in Switzerland – 2024. Leica Geosystems AG is part of Hexagon AB. 903874en – 01.24

Cyrax and HDS are registered trademarks and Cyclone and CloudWorx are trademarks of Leica Geosystems LLC. All other trademarks or registered trademarks are property of their respective owners.

Product functionality is subject to change.

Microsoft, Windows® and the Windows logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and / or other countries.

Leica Geosystems AG Heinrich-Wild-Strasse 9435 Heerbrugg, Switzerland +41 71 727 31 31



- when it has to be right